

TrolMaster

Trolmaster Aqua-x / NFS-1 Infinite Timer Settings

Description: Increase the maximum number of On/Off cycles that the recycling timer function on the Aqua-X has. (Previously limited to 99 “cycles”)

Summary: Each of the 30 available recycling timers on-board the Aqua-X were previously limited to a maximum of 99 On / Off cycles each. That 99 cycle limit was a problem for people operating a NFT style watering schedule, or for any other recycling timer function that occurs frequently.

To set the recycling function for a specific timer to INFINITE (INF):

- 1) Enter the “Start at” time that you want the timer to start timing.
- 2) Now set the “On Time” and Off Time” you want to operate the timer / device.
- 3) Then go to the # of cycles “Times” selection at the bottom of the page. As you scroll through the number of cycles available, you should see INF. Select INF (infinite) to allow the timer to cycle repeatedly until the end of the programmed OFF time for that particular timer.
- 4) If you do not find the INF at the bottom of the list within the “Times” window, the timer settings you have selected are too long and must be shortened.

If you are still having problems, call TrolMaster Tech Support @ 877-420-9876

April 8, 2021